FLOORING REVOLUTION

Maintenance Guide - LVT Flooring

Regular cleaning and maintenance are key to keeping your LVT flooring looking it's best. We have pulled together this helpful guide filled with hints and tips to ensure your new floor stays looking brand new!

General Cleaning

Dirt and loose debris can be removed by daily sweeping or vacuuming, this will help prevent any accidental scratching to your flooring, whilst also keeping it looking its best! To remove dirty footprints from your flooring all you will need is a damp mop and mild cleaning detergent, however please note that damp cleaning should only be done once a week. Ensure that your mop is not too wet and always ring out excess water before use, a microfibre mop is highly recommended.

Maintenance & Up-Keep

It is important to carry out appropriate maintenance procedures to help preserve the appearance and extend the life of your LVT flooring. If the flooring is laid in an area with heavy foot traffic then more frequent maintenance would be required.



Furniture & LVT Flooring

Consideration of external conditions can prevent damage to the flooring and also cut down on cleaning time.

Dirt is most commonly transported indoors by foot traffic and if any dirt gets trapped under sliding furniture the flooring could suffer scratches from the abrasion of the dirt. We advise using protective felt pads on furniture feet to help prevent any unwanted damage. If your LVT flooring has suffered damage such as scratch marks then a floor repair kit is great to help remove these!

Entrance mats

Reduce the risk of slips and falls while also preventing unwanted soiling to your floor with the use of entrance mats. When properly serviced, entrance mats can effectively remove abrasive materials and reduce tracking in water from foot traffic to help keep your LVT flooring clean and mark-free.

- Avoid using entrance mats that have rubber or latex backing/edging as this may cause staining.
- Regular cleaning of your entrance mat and the area surrounding it is strongly advised.

IMPORTANT TO NOTE:

To ensure optimum maintenance and care, we would advise that the following advice be followed:

- · Wiping up any accidental spills as quickly as possible will help minimise the chance of staining.
- Do not use a steam mop or steam cleaning appliances when cleaning your LVT floor.
- Over soaking your floor with water can cause damage, always ensure your mop has been wrung out before use.
- Take caution after mopping the floors as wet LVT can become slippery.
- · Avoid using abrasive cleaning equipment or floor wax on your LVT flooring.
- · Avoid placing LVT flooring in direct sunlight as this can cause fading over time.